

Curbeez Mounting Instructions

1. Raise plow blade and block for safety.
2. Remove two cutting edge bolts on each end of cutting edge.
3. Install Curbeez on each end of plow with hardware provided.
4. Remove blocking and lower plow.
5. From the outside to in, 12" wide – 10" high – slide rubber tightly along saddle, until it touches the cutting edge and mark the rubber through the saddle mounting holes for drilling.
6. Drill through rubber at marked locations. **NOTE:** For best results – use 1/4" drill bit to start, and finish with a 3/4" drill bit to achieve a 1/2" hole through rubber.
7. Use flat washers on carriage bolts through the front of the rubber and tighten until washer sinks into rubber, just below the surface of the rubber.



Sold and distributed by Richard's Certified Welding
639 Whitney Road West • Fairport, New York 14450

585-388-1100 www.curbeez.com